Trademarks

FOXWELL is trademark of Shenzhen Foxwell Technology Co., Ltd. All other marks are trademarks or registered trademarks of their respective holders.

Copyright Information

©2015 Shenzhen Foxwell Technology Co., Ltd. All rights reserved.

Disclaimer

The information, specifications and illustrations in this manual are based on the latest information available at the time of printing.

Foxwell reserves the right to make changes at any time without notice.

Visit our website at:

www.foxwelltech.com

For Technical Assistance, send us email at

support@foxwelltech.com

One-Year Limited Warranty

Subject to the conditions of this limited warranty, Shenzhen Foxwell Technology Co., Ltd ("FOXWELL") warrants its customer that this product is free of defects in material and workmanship at the time of its original purchase for a subsequent period of one (1) year.

In the event this product fails to operate under normal use, during the warranty period, due to defects in materials and workmanship, FOXWELL will, at its sole option, either repair or replace the product in accordance with the terms and conditions stipulated herein.

Terms and Conditions

1 If FOXWELL repairs or replaces the product, the repaired or replaced product shall be warranted for the remaining time of the original warranty period. No charge will be made to the customer for replacement parts or labor charges incurred by FOXWELL in repairing or replacing the defective parts.

2 The customer shall have no coverage or benefits under this limited warranty if any of the following conditions are applicable:

a) The product has been subjected to abnormal use, abnormal conditions, improper storage, exposure to moisture or dampness, unauthorized modifications, unauthorized repair, misuse, neglect, abuse, accident, alteration, improper installation, or other acts which are not the fault of FOXWELL, including damage caused by shipping.

b) The Product has been damaged from external causes such as collision with an object, or from fire, flooding, sand, dirt, windstorm, lightning, earthquake or damage from exposure to weather conditions, an Act of God, or battery leakage, theft, blown fuse, improper use of any electrical source, or the product was used in combination or connection with other product, attachments, supplies or consumables not manufactured or distributed by FOXWELL.

3 The customer shall bear the cost of shipping the product to FOXWELL. And FOXWELL shall bear the cost of shipping the product back to the customer after the completion of service under this limited warranty.

4 FOXWELL does not warrant uninterrupted or error-free operation of the product. If a problem develops during the limited warranty period, the consumer shall take the following step-by-step procedure:

a) The customer shall return the product to the place of purchase for repair or replacement processing, contact your local FOXWELL distributor or visit our website www.foxwelltech.com to get further information.

b) The customer shall include a return address, daytime phone number and/or fax number, complete description of the problem and original invoice specifying date of purchase and serial number.

c) The customer will be billed for any parts or labor charges not covered by this limited warranty.

d) FOXWELL will repair the Product under the limited warranty within 30 days after receipt of the product. If FOXWELL cannot perform repairs covered under this limited warranty within 30 days, or after a reasonable number of attempts to repair the same defect, FOXWELL at its option, will provide a replacement product or refund the purchase price of the product less a reasonable amount for usage.

e) If the product is returned during the limited warranty period, but the problem with the product is not covered under the terms and conditions of this limited warranty, the customer will be notified and given an estimate of the charges the customer must pay to have the product repaired, with all shipping charges billed to the customer. If the estimate is refused, the product will be returned freight collect. If the product is returned after the expiration of the limited warranty period, FOXWELL' normal service policies shall apply and the customer will be responsible for all shipping charges.

5 ANY IMPLIED WARRANTY OF MERCHANTABILITY, OR FITNESS FOR A PARTICULAR PURPOSE OR USE, SHALL BE LIMITED TO THE DURATION OF THE FOREGOING LIMITED WRITTEN WARRANTY. OTHERWISE, THE FOREGOING LIMITED WARRANTY IS THE CONSUMER'S SOLE AND EXCLUSIVE REMEDY AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. FOXWELL SHALL NOT BE LIABLE FOR SPECIAL, INCIDENTAL, PUNITIVE OR CONSEQUENTIAL DAMAGES, INCLUDING BUT NOT LIMITED TO LOSS OF ANTICIPATED BENEFITS OR PROFITS, LOSS OF SAVINGS OR REVENUE, LOSS OF DATA, PUNITIVE DAMAGES, LOSS OF USE OF THE PRODUCT OR ANY ASSOCIATED EQUIPMENT, COST OF CAPITAL, COST OF ANY SUBSTITUTE EQUIPMENT OR FACILITIES, DOWNTIME, THE CLAIMS OF ANY THIRD PARTIES, INCLUDING CUSTOMERS, AND INJURY TO PROPERTY, RESULTING FROM THE PURC HASE OR USE OF THE PRODUCT OR ARISING FROM BREACH OF THE WARRANTY, BREACH OF CONTRACT, NEGLIGENCE, STRICT TORT, OR ANY OTHER LEGAL OR EQUITABLE THEORY, EVEN IF FOXWELL KNEW OF THE LIKELIHOOD OF SUCH DAMAGES. FOXWELL SHALL NOT BE LIABLE FOR DELAY IN RENDERING SERVICE UNDER THE LIMITED WARRANTY, OR LOSS OF USE DURING THE PERIOD THAT THE PRODUCT IS BEING REPAIRED.

6. Some states do not allow limitation of how long an implied warranty lasts, so the one-year warranty limitation may not apply to you (the Consumer). Some states do not allow the exclusion or limitation of incidental and consequential damages, so certain of the above limitations or exclusions may not apply to you (the Consumer). This limited warranty gives the Consumer specific legal rights and the Consumer may also have other rights which vary from state to state.

Safety Information

For your own safety and the safety of others, and to prevent damage to the equipment and vehicles, read this manual thoroughly before operating your tool. The safety messages presented below and throughout this user's manual are reminders to the operator to exercise extreme care when using this device. Always refer to and follow safety messages and test procedures provided by vehicle manufacturer. Read, understand and follow all safety messages and instructions in this manual.

Safety Message Conventions Used

We provide safety messages to help prevent personal injury and equipment damage. Below are signal words we used to indicate the hazard level in a condition.

A DANGER

Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury to the operator or to bystanders.

A WARNING

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury to the operator or to bystanders.

A CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in moderate or minor injury to the operator or to bystanders.

Important Safety Instructions

And always use your tool as described in the user's manual, and follow all safety messages.

A WARNING

• Do not route the test cable in a manner that would interfere with driving controls.

• Do not exceed voltage limits between inputs specified in this user's manual.

• Always wear ANSI approved goggles to protect your eyes from propelled objects as well as hot or caustic liquids.

• Fuel, oil vapors, hot steam, hot toxic exhaust gases, acid, refrigerant and other debris produced by a malfunction engine can cause serious injury or death. Do not use the tool in areas where explosive vapor may collect, such as in below-ground pits, confined areas, or areas that are less than 18 inches (45 cm) above the floor.

• Do not smoke, strike a match, or cause a spark near the vehicle while testing and keep all sparks, heated items and open flames away from the battery and fuel / fuel vapors as they are highly flammable.

• Keep a dry chemical fire extinguisher suitable for gasoline, chemical and electrical fires in work area.

• Always be aware of rotating parts that move at high speed when an engine is running and keep a safe distance from these parts as well as other potentially moving objects to avoid serious injury.

• Do not touch engine components that get very hot when an engine is running to avoid severe burns.

• Block drive wheels before testing with engine running. Put the transmission in park (for automatic transmission) or neutral (for manual transmission). And never leave a running engine unattended.

• Do not wear jewelry or loose fitting clothing when working on engine.

Table of Contents

ONE-YEAR LIMITED WARRANTY	2
SAFETY INFORMATION	5
SAFETY MESSAGE CONVENTIONS USED	5
IMPORTANT SAFETY INSTRUCTIONS	5
1 USING THIS MANUAL	10
1.1 Bold Text	10
1.2 Symbols and Icons	10
1.2.1 Solid Spot	10
1.2.2 Arrow Icon	
1.2.3 Note and Important Message	10
2 INTRODUCTION	11
2.1 SCANNER DESCRIPTIONS	11
2.2 ACCESSORIES	13
2.3 TECHNICAL SPECIFICATIONS	15
3 GETTING STARTED	16
3 GETTING STARTED 3.1 Powering up the Scanner	
3.1 POWERING UP THE SCANNER	16
3.1 POWERING UP THE SCANNER	16
 3.1 POWERING UP THE SCANNER. 3.1.1 Vehicle Power. 3.1.2 Internal Battery Pack. 3.1.3 12V AC/DC Power Supply. 	16
 3.1 POWERING UP THE SCANNER 3.1.1 Vehicle Power 3.1.2 Internal Battery Pack 3.1.3 12V AC/DC Power Supply 3.2 SHUTTING DOWN THE SCANNER 	16 16 16 16 17
 3.1 POWERING UP THE SCANNER	
 3.1 POWERING UP THE SCANNER	
 3.1 POWERING UP THE SCANNER	16 16 16 16 16 17 17 17 18 18
 3.1 POWERING UP THE SCANNER	16 16 16 16 16 17 17 17 18 18
 3.1 POWERING UP THE SCANNER	16 16 16 16 17 17 17 17 18 18 18 19
 3.1 POWERING UP THE SCANNER	
 3.1 POWERING UP THE SCANNER	
 3.1 POWERING UP THE SCANNER	

4.1.4 Windows Tool Bar	20
4.2 VEHICLE IDENTIFICATION	20
4.2.1 Automatic VIN Aquisition	21
4.2.2 Manual VIN Entry	23
4.3.3 Manual Vehicle Selection	
4.3 SYSTEM SELECTION	25
4.3.1 Auto Scan	25
4.3.2 Control Unit	27
4.4 DIAGNOSTIC OPERATIONS	
4.4.1 ECU Information	29
4.4.2 Read Codes	
4.4.3 Freeze Frame Data	31
4.4.4 Erase Codes	
4.4.5 Live Data	
4.5.5.1 All Data	33
4.5.5.2 Custom Data List	
4.5.5.3 Study And Comparison Mode of Live Data	
5 BI-DIRECTIONAL TEST OPERATIONS	
5.1 ACTIVE TESTS	39
5.2 ADAPTATION	41
5.3 Coding and Programming	42
6 SERVICE AND MAINTENANCE OPERATIONS	43
6.1 OIL LIGHT RESET	43
6.1.1 Oil Reset With One Button	
6.1.2 Manual Reset	44
6.1.3 Auto Reset	
6.2 ELECTRONIC PARKING BRAKE (EPB) SERVICE	
6.3 TIRE PRESSURE MONITORING SYSTEM (TPMS) PROGRAMMING	48
6.4 ABS/AIRBAG SERVICES	
6.5 STEERING ANGLE SENSOR (SAS) CALIBRATION	
6.6 DIESEL PARTICULATE FILTER (DPF) REGENERATION	
	40

⁷ DATA MANAGEMENT OPERATIONS......49

7.1 Browse Picture	49
7.1.1 How to Take a Screenshot	
7.1.2 Review Screenshot	
7.2 PLAYBACK DATA	
7.3 DATA LOGGING & STORED DATA MANAGEMENT	
8 CLIENT MANAGEMENT	
9 REMOTE CONTROL	52
10 SETTING	53
10.1 LANGUAGE	54
10.2 Change Display Mode	54
10.3 Change Units	54
10.4 USER INFORMATION	
10.5 RESET SETTING	55
11 ABOUT	55
12 REGISTRATION AND UPDATE	56
12.1 CREATE A FOXWELL ID	56
12.1.1 Register with Built-in Update Client FoxScanner	56
12.1.2 Register through Website	59
12.2 REGISTER YOUR SCANNER	64
12.2.1 Register Through Website	64
12.2.2 Register With Built-in Update Client FoxScanner	66
12.3 Update the Scanner	67

1 Using This Manual

We provide tool usage instructions in this manual. Below are the conventions we used in the manual.

1.1 Bold Text

Bold text is used to highlight selectable items such as buttons and menu options.

Example:

Press the ENTER button to select.

1.2 Symbols and Icons

1.2.1 Solid Spot

Operation tips and lists that apply to specific tool are introduced by a solid spot $\bullet.$

Example:

When System Setup is selected, a menu that lists all available options displays. Menu options include:

- Languages
- Display Mode
- Unit
- User Information
- Resetting

1.2.2 Arrow Icon

► An arrow icon indicates a procedure.

Example:

To connect to wall plug:

- 1. Connect the 12V power adapter to scanner and plug it to the wall socket.
- 2. Press the power switch of the scan tool to power it on; meanwhile the

scanner tool starts charging automatically also.

1.2.3 Note and Important Message

Note

A NOTE provides helpful information such as additional explanations, tips, and comments.

Example:

NOTE

Test results do not necessarily indicate a faulty component or system.

Important

IMPORTANT indicates a situation which, if not avoided, may result in damage to the test equipment or vehicle.

Example:

IMPORTANT

Do not soak scanner as water might find its way into the scanner.

2 Introduction

GT80, a next generation diagnostic tool from Foxwell, provides professional diagnosis on more than 58 American, Asian and European vehicle makes. It has access to a vast range of controllers (ABS, airbags, instrument cluster, etc.), live sensor data, and system/component-level bi-directional controls to get the job done faster and with a greater degree of accuracy and prevent dreaded "comeback". In addition, it has access to the most commonly required service features like brake deactivation, service resets, and transmission adaptations.

2.1 Scanner Descriptions

This section illustrates external features, ports and connectors of the scanner.



Figure 2-1 Front View

1 **10.1**" **LED IPS Capacitive Touch Screen** - shows menus, test results and operation tips.

2 Loud Speaker

- 3 Front-Facing Camera provides face to face technical support or communication.
- 4 **Communication Status Indictator** shows the communication status between the scanner and vehicle.
- 5 Power Status Indicator indicates the power status of the scanner.
- 6 Home Button exits a screen and returns to the home screen of the tablet.



Figure 2-2 Back View

- 1 **Battery Compartment** installs lithium-polymer battery to provide power to the scanner when disconnected from vehicle.
- 2 **Collapsible Stand** extends from the back to allow hands-free viewing of the display. The stand clips into the unit for storage and pivots out so the display is at a 45 degree angle when in use.
- 3 Rear-Facing Camera takes pictures of VIN number, faulty parts and plates and shoots test videos.



Figure 2-3 Top View

- 1 **Power Switch** turns on the scanner, goes to sleep mode or wake up the scanner from sleep mode, press and hold for 3 seconds for emergency shutdown.
- 2 **USD Port** provides a USB connection for the PC or laptop.
- 3 HDMI (high-definition multimedia interface) Port outputs display of the scanner for demonstration and training of the products.
- 4 Diagnostic Port provides connection between vehicle and the scanner.

5 **DC Power Input Jack -** connects to wall plug to provide power to the scanner and to charge the scanner.

IMPORTANT

Do not use solvents such as alcohol to clean display. Use a mild nonabrasive detergent and a soft cotton cloth.

2.2 Accessories

This section lists the accessories that go with the scanner. If you find any of the following items missing from your package, contact your local dealer for assistance.

Item	Item
DB15 Data Cable	OBDII Adapter
AC/DC External Power	AC/DC External
Adapter	Power Cord
	Mercedes Benz
Audi 4 Pin Adater	38 Pin Adapter
Clip Cable	Cigarette Lighter
Toyota 22 Pin Adapter	Fiat 3 Pin Adater
GM/Daewoo 12 Pin Adapter	Honda 3 Pin Adapter
Kia 20 Pin Adapter	Mitsubishi 12+16 Pin Adapter
Nissan 14 Pin Adapter	Toyota 17 Pin Adapter
BMW 20 Pin Adapter	USB Cable

Table 2-1 Accessories

2.3 Technical Specifications

Item	Description
Operation System	WINDOW 8.1 Pro
Processor	Intel(R) Atom Quad-Core CPU Z3735F 1.33G Hz
Memory	2GB RAM
SSD Hard drive	32GB
SD Card	16GB
System Type	32-bit operating Systems, x64-based processor
Display	Backlit 1280*800 pixel 10.1" TFT color capacitive screen with resistive touch panel
Communication interface	Built-in WIFI 802.11 b/g Wireless LAN USB2.0 Bluetooth04
Sensors	Gravity accelerometer, Ambient Light Sensor (ALS)
Camera	Front –facing and rear-facing
Audio Input /Output	Microphone and dual Speaker
Working Temperature	0 to 60 ℃ (32 to 140 °F)
Storage Temperature	-20 to 70℃ (-4 to 158℉)
Humidity	≤90%
External Power	8-18 Volts powered by vehicle battery
Built-in Battery	7000 mAh, Lithium-polymer battery, chargeable via 12V AC/DC power supply
Protocols	ISO9141-2, ISO14230-2, ISO15765-4, K/L lines, Double K Line SAE-J1850 VPW, SAE-J1850PWM, CAN ISO 11898, High-speed, Middle-speed, Lows-peed and Single wire CAN, KW81, KW82, GM UART, UART Echo Byte Protocol, Honda Diag-H Protocol, TP2.0, TP1.6, SAE J1939, SAE J1939, SAE J1708, Fault-Tolerant CAN
Dimensions	320*220*55mm
Weight	NW: 1.55KG
Weight	GW: 8.65KG

Table 2-2 Technical Specifications

3 Getting Started

This section describes how to power on/down the scanner, provides brief introductions of applications loaded on the scanner and display screen layout of the scan tool.

3.1 Powering up the Scanner

Before using the GT80 applications (including updating the scanner), please make sure to provide power to the scanner.

The unit operates on any of the following sources:

- Vehicle power
- Internal Battery Pack
- 12V AC/DC Power Supply

3.1.1 Vehicle Power

The scanner can be powered on by connecting to the data link connector (DLC) of the vehicle through a direct cable connection.

- To connect to vehicle power:
 - 1.Locate the data link connector (DLC). The DLC is generally located under the dash on the driver side of the vehicle.
 - 2.Attached the diagnostic cable to the scanner and tighten the captive screws to ensure good connection.
 - 3. Connect a correct adapter to the data cable according to the vehicle being serviced and plug it into the vehicle DLC.
 - 4. Switch the ignition key to the ON position.
 - 5. Press the power switch on the top of the scanner for 5 seconds and it automatically boots up.

3.1.2 Internal Battery Pack

The tablet scanner can be powered with the internal rechargeable battery. The fully charged battery is capable of providing power for 6.5 hours of continuous operation.

3.1.3 12V AC/DC Power Supply

The scan tool can also be powered from a wall socket using the AC/DC power supply. The AC/DC power supply also powers the internal battery pack charging.

To connect to wall plug:

1. Connect the 12V power adapter to scanner and plug it to the wall socket.

2. Press the power switch of the scan tool to power it on; meanwhile the scanner tool starts charging automatically also.

3.2 Shutting Down the Scanner

All vehicle communication must be terminated before shutting down the scanner. Forcing a shut down while communicating may lead to ECM problems on some vehicles. Exit the Diagnostic application before powering down.

- To shut down the scanner:
 - 1. Swipe the rightmost side of the display and you will see the Settings icon of the Windows system.
 - 2. Press the Settings icon and you will see the Power switch.
 - 3. Press the Power switch and select the shut down option to power the

scanner off.

NOTE

In case of emergency, press and hold the Power button of the scanner for 5 seconds to force shutdown.

3.3 Screen Layout of Home Screen

When the scan tool boots up, press the Desktop tab from the Home screen of the tablet. Then press the GT80 desktop icon twice to launch the diagnostic application.



Figure 3-1Sample Home Screen

- 1. Title Bar
- 2. Application Buttons
- 3. Windows Tool Bar

3.3.1 Title Bar

Operation of the buttons located on the title bar are described in the table below:

Name	Button	Description
Time	00:44:19	Displays current time
Data Logging	0	Records the communication data between the scan tool and the vehicle under test to help with troubleshooting of diagnostic failures. The logs will be saved to the scanner and sent to our server via internet.
Camara	Ō	Captures the screens of errors or faults.
USB Connection Status Indicator	¥	Indicates the USB connection status between the built-in vehicle communication interface and the display. Green USB icon indicates the USB connection has built correctly, while a white icon indicates the connection has not built yet.
Exit	\times	Exits the Diagnostic application or exits a function.

Table 3-2 Title Bar

3.3.2 Application Buttons

This section briefly introduces the applications that are preloaded into the scanner:

- **Diagnostic** leads to test screens for diagnostic trouble code information, live datastream, ECU information, active tests, coding and other functions.
- Data Management leads to screens for saved screenshots and pictures and playing back recorded live datastream, as well as stored logging data.
- **Customer Management** leads to screens for logging and managing the client information of the workshop.
- **Remote Desktop** leads to the application TeamViewer for remote control when you need any support from Foxwell support team.

- **Update** leads to screens for registration and updating of the scanner and managing your scanner serial numbers and sending us feedbacks about the scanner.
- **Setting** leads to screens for adjusting default settings to meet your own preference and view information about the scanner.
- About leads to screen of product information such as serial number and password, which is required for product registration.



Figure 3-3 Sample Application Screen

3.3.3 Windows Toolbar

This is the standard Windows 8.1 toolbar. GT80 is a fully functional personal computer based on the Windows 8.1 operating system.

NOTE

In case of the display mode of GT80 application is set to full screen display, the Windows toolbar will not be displayed.

4 Diagnostic Operations

This section illustrates how to use the scanner to read and clear diagnostic trouble codes, view "live" data readings and ECU information on controllers installed, preform special functions such as actuation and coding, and perform vehicle services and maintenances on 58 vehicle brands.

4.1 Screen Layout of Diagnostic Screens

The diagnostics screens typically include four sections.



- Figure 4-1 Title Bar
- 1. Main Body
- 2. Diagnostic Function Buttons
- 3. Windows Tool Bar

4.1.1 Title Bar

Refer to 3.3.1 Title Bar for details.

4.1.2 Main Body

Screens of the Main Body may vary depending on different operations. Main Body displays menus options, test results, messages, instructions and other diagnostic information.

4.1.3 Diagnostic Function Buttons

Diagnostic Function Buttons are used to execute commands and operations. Buttons displayed in each screen may vary depending on different operations.

4.1.4 Windows Tool Bar

Refer to <u>3.3.3 Windows Tool Bar</u> for details.

4.2 Vehicle Identification

The vehicle identification information presented is provided by the ECM of the vehicle being tested. Therefore, certain attributes of the test vehicle must be entered into the scan tool to ensure the data displays correctly. The vehicle identification sequence is menu driven, you simply follow the screen prompts and make a series of choices. Each selection you make advances you to the next screen. A Back button in the upper left corner of the screen returns to the previous screen. Exact procedures may vary somewhat by vehicle. It typically identifies a vehicle by any of the following means:

- Automatic VIN aquisition
- Manual VIN entry
- Manual vehicle selection

NOTE

Not all identification options listed above are applicable to all vehicles. Available options may vary by vehicle manufacturer.

4.2.1 Automatic VIN Aquisition

Automatic VIN Acquisition allows to identify a vehicle by automatically requesting the vehicle identification number (VIN).

To identify a vehicle automatic VIN acquisition:

1. Select **Diagnostic** from the Home screen of the GT80 application.



Figure 4-2 Sample Home Screen

2.A screen with vehicle manufacturers displays. Select the area where the vehicle manufacturer is from. A menu of all vehicle manufacturers from this area displays. Or tap the **Search Vehicle** box to input the vehicle brand to search.



21 Automotive Diagnostic System GT80_English_V1.00

Figure 4-3 Sample Vehicle Selection Screen

3.Select the manufacturer of the test vehicle from the list, and the following screen displays.



Figure 4-4 Sample Vehicle Selection Screen

4. Press Read button to start reading the Vehicle Specification or VIN Code automatically.



Figure 4-5 Sample Vehicle Selection Screen

5. After the scan tool builds connection to the vehicle, the VIN number displays. If the Vehicle Specification or VIN code is correct, press the **OK** to continue. If it is incorrect, you are required to enter the correct VIN number manually.



Figure 4-6 Sample VIN Reading Screen

4.2.2 Manual VIN Entry

Manual VIN Entry identifies a vehicle by manually inputing a 17-digit VIN code.

- ▶ To identify a vehicle by manual VIN entry:
 - 1. Refer to Step 1-3 of 4.1.1 Automatic VIN Acquisition.
 - 2.Press **Keyboard** button to input a valid VIN code and press **OK** to continue. The scan tool starts to identify the vehicle.

				ij4	Please	input	the VIN	l code						
				Ľ					•					
							the VIN							
			Fox	well 1	echn	ology	Co.,Li	td. Al	right	ts res	erved.		×	
1	2	3	4	5	6	1 7	8	9	0	-	=	1	Backspace	
	q		e	r	t	у		i	0	p	I	1	A.	I
	a	s	d	f	g	h	j	k		;			Enter	
								m						
			Shift						Spa	ce				

Figure 4-7 Sample Manual VIN Entry with Keyboard

4.3.3 Manual Vehicle Selection

Manual Vehicle Selection identifies a vehicle by making several selections according to certain VIN characters, such as model year, and engine type.

- ▶ To identify a vehicle by manual vehicle selection:
 - 1. Refer to Step 1-3 of 4.1.1 Automatic VIN Acquisition.
 - 2.On each screen that appears, select the correct option and then press the **OK** button. Do this until the complete vehicle information is entered and the menu of controller selection displays.



Figure 4-8 Sample Manual Vehicle Selection Screen

4.3 System Selection

When you have completed the identification of vehicle, a menu for selecting system to test displays. Menu options typically include:

- Auto Scan
- Control Unit

4.3.1 Auto Scan

Auto Scan performs an automatic system test to determine which control modules are installed on the vehicle and obtain diagnostic trouble codes (DTCs) overview. Depending on the number of control modules, it may take a few minutes to complete the test.

To perform an automatic system scan: 1.Press **Auto Scan** option to start.



Figure 4-9 Sample Select System Scan Screen

2. To pause the scan, press the **Pause** button on the screen.

	Auto Scan	
1 Engine Control Module	42%	No Comm.
2 Fuel Injector Control Module		No Comm.
3 Fuel Pump Control Module		No Comm.
4 Transmission Control Module		No Comm.
5 Rear Differential Clutch Control Module		No Comm.
6 Electronic Brake Control Module		No Comm.
7 Parking Brake Control Module		No Comm.
8 Body Control Module		Pause

Figure 4-10 Sample Auto System Scan Screen

3.At the end of successful automatic controller scan, a menu with a list of installed controllers together with their **DTC overview** displays.



25 Automotive Diagnostic System GT80_English_V1.00

Figure 4-11 Sample Auto Scan Complete screen

4. If there is diagnostic trouble code(s) detected in a control unit, press the **Report** button on the screen to view details of code information, and press **Quick Erase** button to clear them.

		Status Report
Status	DTC Counts	System Mame
Fault	38	PCM
DTC Code	DTC Status	DTC Content
P0102-00	Temporary	Mass or volume air flow circuit low input.
P0108-00	Temporary	Manifold absolute pressure/barometric sensor high input.
P0183-00	Temporary	Fuel temperature sensor A circuit high input
P0113-00	Temporary	Intake air temperature sensor 1 - circuit high input
P0198-00	Temporary	Engine oil temperature sensor circuit high input
P0069-00	Temporary	Manifold absolute pressure - barometric pressure correlation.
E 1		1 4

Figure 4-12 Sample Status Report screen

	11:19:20 💿 👩 🖞 🗙
Auto Scan	
160%	
1 PCM - Powertnun skintet module	Teat 131
GTeo	
Are your sure to evere coder!	
THE NO.	
	1 I
Dr OK Datà Fian Beyer Sev	100 - 1 1 - 1 - 100 - 1000

Figure 4-13 Sample Quick Erase screen

5. When running auto scanning, you can click **Pause** and select the system you would like to test. When the scanner has established connection with the vehicle, the Function Menu displays.

		11:28:27 💿 🧑	$\Psi \times$	
-	Auto Scan			
- PCN - Powerman contra mor			11:28:21	💿 🖻 🖞 🗡
2 SASM - Steering angle senso		Select diagnostic Function		
a brown blowing ange sense	1 ECU Information			
	2 Read Codes			
	3 Erase Codes			
	4 Live Data			
	🖽 🤗 🚆 🐐 🥒			105 - 10 1 = 1 - 04 - 105 - 105

Figure 4-14 Sample Function Menu screen

4.3.2 Control Unit

Control Unit screen displays all controllers available of the vehicle manufacturer. The controllers listed on the menu do not mean that they are installed on the vehicle. It is useful for technicians who are familiar with the vehicle specifications.

- **b** To select a system for testing:
 - 1. Press Control Unit from the menu and a controller menu displays.

	u	01:01:52	0 0 4	\times	
	Main Groups				
1 Auto Scan					
2 Control Line	V5.01 FOXWELL		01:01	56 • 0	$ \Psi \times$
3 Vehicle Information		System			
4 Special Function	1 ATCM - All terrain control module				
5 Service interval reset.	2 CCM - Speed control module				
6 Electronic parking brake	3 FLM - Front lighting control module				
	4 IPC - Instrument cluster control module.				
	5 PBM - Parking brake control module				
	6 PCM - Powertrain control module				
	7 RCM - Restraints control module				
	8 RDCM - Rear differential control module				
	9 RLM - Ride level control module				
	10 SASM - Steering angle sensor module				
	11 TCCM - Transfer case control module				
	e a v				

Figure 4-15 Sample Control Unit Menu Screen

2.Select the system you would like to test. When the scanner has established connection with the vehicle, the **Function Menu** displays.

	iu.	01:02:04	001	$^{\prime}$ \times		
1 ATCM - All terrain co. A				17:34:19	OŌ	Ψ×
2 CCM - Speed control		Functio	n Menu	17.34.19		Y ^
3 FLM - Front lighting o	Read Codes					^
5 PBM - Parking brake	2 Freeze Frame Data					
e PCM Powentian co	ECU Information					- 1
	Live Data					
9 RLM - Ride level cor 10 SASM - Steering and						-
11 TCCM - Transfer car						_
🛋 e 🙀 🛛						
						ENG P2015-03-25

Figure 4-16 Sample Common menu screen

4.4 Diagnostic Operations

After a system is selected and the scanner establishes communication with the vehicle, the Function Menu displays. Generally the menu options are:

- ECU Information
- Read Codes
- Freeze Frame Data
- Erase Codes
- Live Data

NOTE

Not all function options listed above are applicable to all vehicles. Available options may vary by the year, model, and make of the test vehicle. A "The selected mode is not supported!" message displays if the option is not applicable to the vehicle under test.

4.4.1 ECU Information

ECU Information screen displays the identification data of the control module under test, such as the control module identification string and the control module coding.

To read ECU information:

1. Press ECU Information from Select Diagnostic Function menu.



Figure 4-17 Sample Function Menu Screen

2. A screen with detailed information of the selected control module displays.

V5.01 FOXWELL	00:56:19 💽 🙆 🖞 🗙			
	ECU Information			
Vehicle Identification Number	SALAE25456A411919			
Hardware Number	NNN500451			
ECU Software Number	NNV507170			
ECU Serial Number	54688			
Homologation number	A0077			
ECU Core Assembly Number	NNN500451			
ECU Assembly Number				
ECU Delivery Assembly Number	NNN500451			
Boot Software Identification	7NNN500451			
Active Network Configuration Number	2			
OBD INFOTYPES Supported	U			
🕇 e 🔮 e 🦻				

Figure 4-18 Sample ECU Information Screen

3. Press function key **Save** to store ECU information, and press **Print** to print the information. Or use the **ESC** button to exit.

4.4.2 Read Codes

Read Codes menu lets you read trouble codes found in the control unit. Typical menu options include:

- Present/Permanent/Current Codes
- Pending Codes
- History Codes
- Code History
- Self Diagnostic

Present/Permanent/Current codes stored in a control module are used to help identify the cause of a trouble or troubles with a vehicle. These codes have occurred a specific number of times and indicate a problem that requires repair. Pending codes are also referred to as maturing codes that indicate intermittent faults. If the fault does not occur within a certain number of drive cycles (depending on vehicle), the code clears from memory. If a fault occurs a specific number of times, the code matures into a DTC and the MIL illuminates or blinks.

History codes are also referred to as past codes that indicate intermittent DTCs that are not currently active. Code history is number of engine starts since the DTC(s) were first detected (to see if they are current or intermittent).

Self diagnostic lets you manually activate system tests that check for DTCs. Usually it includes a KOEO (Key-on, engine-off) test and a KOER (key-on, engine-running) test.

To read codes from a vehicle:

1. Press **Read Codes** from Select Diagnostic Function menu. A code list including code number and its description displays.

V5.01 FO	XWELL	00:56:08 💽 🙆 🖞 🗙
	Select diagnostic	Function
1 ECU Informat	ion .	
2 Read Codes		
3 Erase Codes		00:56:19 💿 🐻 🖞 🗙
4 Live Data		ECU Information
	Vehicle (dentification Number	SALAE25456A411919
	Hardware Number	NNN500451
	ECU Software Number	NNV507170
	ECU Serial Number	54688
	Homologation number	A0077
	ECU Core Assembly Number	NNN500451
	ECU Assembly Number	
10	ECU Delivery Assembly Number	NNN500451
u e ,	Boot Software Identification	7NNN500451
	Active Network Configuration Number	?
	OBD INFOTYPES Supported	U
	e e e e	

Figure 4-19 Sample Function menu screen

- 2.Slide up and down to view additional information when necessary.
- 3. Press Save to store DTC information, and press **Print** to print the code information. Or use the **ESC** button to exit.

4.4.3 Freeze Frame Data

Freeze Frame Data menu displays freeze frame data, a snapshot of critical vehicle operating conditions automatically recorded by the on-board computer at the time of the DTC set. It is a good function to help determine what caused the fault.

- To view freeze frame data:
 - 1.Select **Freeze Frame Data** from Select Diagnostic Function menu. Details of freeze frame data displays.

/6.13 FOXWE		17:27:10 💽 🙆 🖞 🗙
	Function Menu	
1 Read Codes		^
2 Freeze Frame Data	VB.13 FOXWELL	17:27:50 💿 👩 🦞 🗙
3 Erase Codes		Freeze Frame Data
4 ECU Information	0028*	the second distance of
5 Live Data	Fault Status	01100001
	Fault Priority	0
	Fault Frequency	r,
	Mileage	0 km
	Time indication	0
	RPM	0 /min
_	Load	0.0 %
e	Speed	0.0 km/h
	Temperature	-40 °C
	Temperature	-40 °C

Figure 4-20 Sample function menu screen

- 2. Slide the screen up and down or use the **PAGE UP** and **PAGE DOWN** button to view additional information when necessary.
- 3. Press function key **Save** to store freeze frame information, and press **Print** to print the freeze frame data. Or use the **ESC** button to exit.

4.4.4 Erase Codes

Erase Codes menu lets you to clear all current and stored DTCs from a selected control module. Also it erases all temporary ECU information, including freeze frame. So make sure that the selected system are completely checked and serviced by technicians and no vital information will be lost before clearing codes.

NOTE

- To clear codes, make sure that the ignition key is switched to ON with the engine off.
- Erase Codes does not fix the problem that caused the fault! DTCs should only be erased after correcting the condition(s) that caused them.

To clear codes:

1. Press **Erase Codes** from Select Diagnostic Function menu.

V6.13 FOXWELL	- 1 - 1	17:35:39	00	$\Psi \times$
· · · · · · · · · · · · · · · · · · ·	Function Menu			
1 Read Codes				^
2 Freeze Frame Data				
3 Erase Codes				
4 ECU Information				1
5 Live Data				
Esc			Fage Dp.	Page Down
🛋 🥭 🚞 😻 🧷			🗉 × 🐚 🔃 al (C	ENG 17:35 2015-03-25

Figure 4-21 Sample Function Menu Screen

2.Follow the on-screen instructions and answer questions about the vehicle being tested to complete the procedure.



Figure 4-22 Sample Erase Codes Screen

3. Check the codes again. If any codes remain, repeat the Erase Codes steps.

4.4.5 Live Data

Live Data menu lets you view real time PID data in text, plot and gauge formats, learn good sensor data and compare them with faulty data, and record live data from a selected vehicle electronic control module.

Menu options typically include:

- All Data
- Custom List

4.5.5.1 All Data

All Data menu lets you view all live PID data from a selected control module. GT80 allows you to view live data information in 6 differenct types of display modes.

- **Text Mode** this is the default mode which displays the parameters in texts.
- **Graph Mode** displays the parameters in waveform graphs, giving you the 'real picture' of what's going on in the vehicle. You can view up to 4 parameter graphs simultaneously and easily find and zoom in on a particular string of data.
- Merged Graph Mode merges multiple PID plots into one coordinate, so you can easily see how they affect each other, providing you with the most comprehensive and functional look at live data possible.
- Guage Mode displays the parameters in the form of an analog meter.
- Study Mode gives you the ability to learn good live sensor data values during idle, KEKO, acceleration, deceleration, part load and heavy load on each vehicle comes into your shop and records them for future reference.
- Comparison Mode If that vehicle comes in is with a problem, you can easily compare the faulty sensor and parameter readings to the good readings, and you will be alarmed when a faulty sensor reading is detected.

NOTE

- Study and Comparison modes are available for viewing of parameter readings in text mode ONLY.
- In case no learned value is stored in the scan tool, the Comparison Mode will not be available.
- To view all live PID data:
 - 1. Press **Live Data** from Select Diagnostic Function menu to display the live data menu.



Figure 4-23 Sample Live Data Selection Screen

2.Press **All Data** from the menu to display the data stream screen. All readings will be displayed in text format by default.

		Dat	a List		
Te	axt Graph	Graph Merge	Gauge	Study Mode	Comparison Mode
Index	Name		Reference	Value	Unit
162	Cylinder 4 - Misfine counter			0	
163	Cylinder 5 - Misfire counter			a	
164	Cytinder 6 - Misline counter			0	
165	High speed CAN network management	t state - latest state		Expulsion mode - silent	
186	High speed CAN network management	f state - 2nd latest state		Operation mode	
167	High speed CAN network management	t state - 3rd latest state		CAN initialization	
168	High speed CAN network management	t state - 4th intest state		Start-up	
169	High speed CAN network management	f stale - 5th lidest stale		Start-up	
		a 0	17	1	

Figure 4-24 Sample Complete List Screen

3.Swipe the screen up and down or use the **PAGE UP** and **PAGE DOWN** button to view additional information when necessary.

Text of Index Name of Accelerator penal post 001 Accelerator penal post 002 Accelerator pedal post 003 Throthe position senso	Graph Graph Merge	a List Gauge Reference	Study Mode Value 0.00	Comparison Mod Unit
Index Name 001 Accelerator petial post 002 Accelerator petial post	en D		Value	Unit
001 Accelerator pedal post 002 Accelerator pedal post		Reference		
002 Accelerator pedal post				
	on E			
003 Throttle position sensor			0.00	*
			0.00	
004 Oxygen sensor current sensor).	bank 1 - sensor 1 (wide range oxygen		0	υA
005 Oxygen sensor ourtent sensor).	bank 2 - semior 1 (wide range on/gen		o	иА
006 Barometric pressure			102	kpe
007 Calculated load value			0.00	20

Figure 4-25 Sample Live Data Screen

- 4. To move a data line to the top of Data List screen, just tap the line to select and then press the button **To Top**. To record live data to memory of the scanner for offline review, just tab the button **Record**, and press **Stop** to stop recording at any time. To print the data through computer, tap the **Print** icon.
- 5. To view live PID in graph format, press the tab **Graph**, and 4 PID plots display. To view another PID plot, tab the name of a plot and a list of available PIDs display. Select one from the dropdown box and the plot changes to the newly selected PID. To view the plots with more details, use the **Zoom in** button; instead, use the **Zoom out** button.



Figure 4-26 Sample PID Graph Screen

6. To see how the PIDs affect each other, press the **Graph Merge** tab to merge them into one coordinate for easy and intuitive diagnosis.



Figure 4-27 Sample Graph Merge Screen

7. To view parameters in the form of an analog meter, press the **Guage** tab.



Figure 4-28 Sample PID Gauge Screen

4.5.5.2 Custom Data List

Custom Data List menu lets you to minimize the number of PIDs on the data list and focus on any suspicious or symptom-specific data parameters.

To create a custom data list:

1. Press **Custom List** from the menu to display all available parameters from the selected control module.


Figure 4-29 Sample Live Data Screen

2. The custom data stream selection screen displays. Tap the lines you wish to select.



Figure 4-30 Sample Custom List Selection Screen

NOTE

To deselect an item, tap the line again. Alternatively, tap **SELECT ALL** or **CLEAR ALL** to select or deselect all items at once.

3. Press the **OK** button to complete the selection, and all selected parameters display.

			Da	ta List		
T	ext	Graph	Graph Merge	Gauge	Study Mode	Comparison Mode
Index	Name			Reference	Value	Unit
	Accelerator per	tul picetican D				
002	Oxygen sensor	current, benk 1 - sens	or 1 (wide range oxygen		0	isA
	sensor).					
003	Baromitine pre	ssure			102	kpe
004	Enable status o	continuous monitors t	this monitoring cycle.		7	

Figure 4-31 Sample Live Data Screen

4.5.5.3 Study And Comparison Mode of Live Data

GT80 is able to learns and records good live sensor data values, compares with the faulty sensor and parameter readings to the good readings and warns the technician of the faulty sensor data.

▶ To learn and record good sensor value:

- 1.Connect GT80 to a good vehicle and turn ignition on to build communication with the car.
- 2. Identify the car, select a system to test and then select **Live Data** as descibed above.
- 3. Press **All Data** to display all available parameters from the selected control module. Press **Study Mode**, and a dropdown list of working conditions display.

	Data	a List		
T	ext Graph Graph Merge	Gauge	Study Mode	Comparison Mode
Index	Name	Reference	Study Mode Idle Study Mode KOEO	Unit
007	Calculated load value		Study Mode Acceleration Study Mode Deceleration	*
608	Enable status of continuous monitors this monitoring cycle:		Study Mode Part Load Study Mode Heavy Load	
009	Completion status of continuous monitors this monitoring cycle		Committee	
010	Enable status of non-continuous monitors this monitoring cycle:		Denile factories allows Denime Discontinues	
011	Completion status of non-continuous monitors this monitoring cycle		Desinte Maren a proce	
012	Distance travelled while mailfunction indicator activated		0	
013	Distance since diagnostic trouble codes cleared		65535	
014	Engine coolant temperature		21	ъ.
ms	Exhaust gas recirculation error		0.00	N
714	Communited automaticity rate reprint dation		0.00	*

Figure 4-32 Sample Study Mode Screen

5 Bi-directional Test Operations

GT80 allows you to use the scan tool temporarily activate or control a vehicle system or component. With GT80, the check of electronic components such as switches, sensors, relays, & actuators is made a simple task. It allows you to recalibrate, adapt or configure certain components after making repairs or replacement. It gives you the ability to 'flash' a control unit with new program data. Provided that a module can be re-coded, GT80 allows for the coding and programing of a replacement control module or changing previously stored incorrect coding as expensive factory tools do. In addition, it lets you recode the transponder in a mechanical key or key fob. When a key for a modern vehicle is replaced, the new unit will often turn the mechanical switch but fail to initialize the system or start the vehicle. If this occurs, it is typically because the transponder inside the key has not been coded to that particular system.

5.1 Active Tests

Active Tests also known as Actuator Tests are bi-directional diagnostic tests on vehicle systems and component. The tests let you to use the scanner temporarily activate or control a vehicle system or component, and when you exit the test, the system/component returns to normal operation.

Some tests display a command to the operator. For example, if "Press Brake Pedal" displays, the operator has to press and hold the brake pedal and then continue. The sequence, number, and type of tests are dictated by the control module.

On some systems, the actuator tests cannot be restarted until the ignition key is switched off for some time. Alternatively, briefly start and run the engine, shut down, turn the ignition to the run position, then re-initiate the actuator tests.

IMPORTANT

The tests activate a component, but they do not check if the component is working correctly. Make sure the components to be tested are in good condition and correctly mounted.

NOTE

Available tests depend on the control module under test and the vehicle itself.

To start a test:

1. Press Active Test from the menu and a list of available options displays.

	10:49:59 💿 🙆 🖞 🗙
Active Test	
1 Control the Injection Volume for A/F Sensor	
2 Control the Injection Volume	
3 Activate the VSV for Intake Control	
4 Activate the Fuel Pump Speed Control	
5 Activate the VSV for Evap Control	
6 Control the Fuel Pump/Speed	
7 Connect the TC and TE1	
8 Control the Idle Fuel Cut Prohibit	
9 Control the Electric Cooling Fan	
10 Activate the ACC Cut Relay	
	Page Dawn
	1049 2015/3/39

Figure 5-1 Sample Active Test Screen

2. Select an option to start the test and live data of the selected test displays.

	10:50:11		$^{\prime} \times$
Active	e Test		
Control the Injection Volume for A/F Sensor		-12,5	% ^
ML		OFF	
Number of Emission DTG		0	
Mistire Monitor		Avail	
Fael System Monitor		Avail	
Complete Parts Monitor		Aint	
Catalyst Monitor		Avail	
Heated Catalysi Monitor		Not Avi	
EWAP Monitor		Not Avi	
2nd Air Monitor		Not Avi	
F1 F2		î	Page Down
C 6 7 2	/6	I - Marke	10:50 2015/3/19

Figure 5-2 Sample Active Test Screen

- 3.Follow on-screen instructions to make proper selections and operations to complete the tests.
- 4. To exit the test, tap the **Back** button or the **Close** button at the top right of the screen.

A WARNING

- Before running any tests, always observe the safety instructions provided in this manual and the warnings provided by the vehicle manufacturer. In addition, follow any warnings and descriptions provided on the scanner screens.
- Never run the tests while the vehicle is moving.

5.2 Adaptation

Adaptation menu let you change adaptation values from the control module and allows you to alter certain values and/or settings in control modules that support it.

A WARNING

You should refer to the Service Manual for your particular car before attempting to use the Adaptation function.

To set an adaptation:

1. Select Adaptation from Function Menu and press the ENTER key.

		14:29:46	00	Ψ×
	Function Menu			
1 ECU Information				
2 Read Codes				
3 Erase Codes				
4 Live Data				
5 Active Test				
6 Basic Setting				
7 Anspiron				
8 Coding				_
9 Security Access(Login)				
			Î	
				1 10 14.0

Figure 5-3 Sample Adaptation Screen

2.Follow on-screen instructions to make proper selections and operations to complete the tests.



Figure 5-4 Sample Adaptation Setting Screen

3. To exit the test, tap the **Close** button at the top right of the screen.

5.3 Coding and Programming

GT80 allows for the coding and programing of a replacement control module or changing previously stored incorrect coding.

Coding also known as Teach-in Program or Component Adaptation. It is the process of selecting and activating one program for a specific vehicle from a set of programs that the factory installed in the control module. This allows one control module to be used for different models, countries, and emission applications.

Programming is the process of taking a blank control module and then adding the correct vehicle program to memory.

6 Service and Maintenance Operations

This section gives brief instructions of the most commonly required service and maintenance operations. Typical service operation screens are a series of menu driven executive commands. Follow on-screen instructions to complete the operation.

Available service and maintenance options include:

- Oil Light Reset
- EPB Service
- TPMS Programming Service
- ABS/SRS Services
- SAS Calibration
- DPF Regeneration

6.1 Oil Light Reset

Oil Light Reset menu allows you to reset the service lamps on the instrument cluster. The Service Indicator System is designed to alert the driver when the vehicle is due for a service.

Oil service reset methods are determined by the vehicle being tested. Depending on the vehicle being tested, any of the following means displays:

- Oil Reset With One Button
- Manual Reset
- Auto Reset

6.1.1 Oil Reset With One Button

Oil Reset With One Button is applicable to GM models only. It offers quick and simple oil service reset with the click of one button.

- ► To do Oil Reset With One Button on a year 2010 Chevrolet passenger car model:
 - 1.Scroll with up and down arrow keys to highlight **Oil Life Reset** from the Engine Control Module menu. An Information screen displays. Press the function key **OK** to continue or **Cancel** key to return to the Oil Reset menu.



Figure 6-1 Sample Oil Reset Menu Screen

2.Follow on-screen instruction and send a command to reset oil service. A screen with "Success" message displays once the lamp has been reset. Press any key to return.



Figure 6-2 Sample Oil Reset With One Button Success Screen

6.1.2 Manual Reset

Almost all Asian vehicles and most American and European vehicles have mechanical oil service indicator reset. The service tool does not have to communicate with the vehicle being tested, but guides you to complete the service manually by providing step-by-step on-screen instructions.

When Manual Reset is selected and the vehicle being tested identified, a procedure opens on the screen. Scroll with arrow keys to read the entire procedure and performing the necessary steps as directed by the on-screen instructions. The exact order of the test operation steps may vary depending on the test vehicle. Be sure to follow all on-screen instructions.

This manual reset procedure can be interrupted and aborted if the ignition key position is changed.

- To do oil reset manually:
 - 1.Enter vehicle information by certain VIN characters, such as model, and year to identify the vehicle being tested and press **OK** key to confirm. Select Engine Control Module and follow the on-screen menu to select Oil Life Reset.



Figure 6-3 Sample Vehicle Identification Screens

2. When Oil Life Reset is selected, a procedure screen displays.



Figure 6-4 Sample Manual Reset Instructions Screen

- 3. Follow all on-screen instructions to perform the manual mechanical reset.
- 4.Press **OK** key to return.

6.1.3 Auto Reset

Auto Reset is a bi-directional communication procedure directed by the service tool. The service tool displays guides for you through the process. A number of instructions that require a response to continue display, including an option to clear any stored codes once the interval has been reset. Follow the on-screen instructions.

6.2 Electronic Parking Brake (EPB) Service

EPB Service menu allows you to perform the service and maintenance of brake systems, including deactivation and activation of the brake control system, bleeding brake fluid, opening and closing brake pads, and setting brakes after disc or pad replacement, on multiple brands of vehicles where electronic brake systems are fitted.

Some tests display a command to the operator. For example, if "Pressing Brake Pedal" displays, the operator has to press and hold the brake pedal and then continue. Actual tests vary by vehicle manufacturer, year, make.

Typical special test options include:

- Deactivate/Activate SBC/EPB systems allows to deactivate brakes for further service or maintenance work on brake systems or activate brakes when service or maintenance work on brake systems are completed.
- Adaptation on Audi A8 allows to set new pad thickness of rear brakes calipers after changing brake discs & pads on Audi A8 models.

- Replace hydraulic brake systems fluid/bleed brake system on Mercedes SBC vehicles – allows to change brake fluid/bleed brake system.
- Perform service reset and service position on BMW EPB vehicles allows to do the CBS reset and CBS correction for front brake and rear brake.
- Perform activation/service work on Volvo PBM vehicles allows to perform installation check, applying parking brake, releasing parking brake, activating service mode and exiting service mode.
- Reset memory on Toyota EPB vehicles allows to clear the learned memory of the EPB ECU.
- Perform brake cable replacement and electric parking brake replacement allows to fit in or remove the brake cable safely, adjust brake cable's tension and calibrate the electric parking brake replacement.
- Save and write clutch pedal programming on Renault EPB vehicles allows to save clutch pedal programming on Renault vehicles fitted with manual gearbox. After this command is activated, the tool allows to "flash" the electric parking brake unit with the saved clutch data.
- Perform control function and reset function on Opel EPB vehicles allows to apply/release park brake cable service, provide park brake cable service replacement procedures and calibrate the parking brake systems after brake service.
- Sensor calibration on Honda EPB vehicles allows to program the current output value of each sensor into the electric parking brake unit.
- Provides parking brake unjam procedure and perform longitudinal accelerometer calibration on Land Rover EPB vehicles – allows to drive the electronic park brake so it is unjamed in the releasing direction and then drive it into mounting position or the latching position; also allows to perform longitudinal accelerometer calibration.

A WARNING

- EPB systems must be deactivated before carrying out any maintenance/service work on the brakes such as changing of pads, discs and calipers.
- Use proper tools to avoid the risk of body injuries of mechanics and technicians and damage to the brake system.
- Make sure the vehicle is properly blocked after deactivation of the systems.

6.3 Tire Pressure Monitoring System (TPMS)

Programming

TPMS Service menu allows you to check the tire sensor IDs from the vehicle ECU and to perform TPMS programming and reset after tires and/or TPM sensors are replaced and/or tires are rotated.

6.4 ABS/Airbag Services

ABS/Airbag Services menu let you use the scanner temporarily to activate or control anti-lock brake systems and air bags or components.

Typical test options include:

- ABS Manual Control Tests–allows to manually control the actuators in order to test ABS motors, solenoids, solenoid enable relays, EMBs, and more.
- ABS Motor Test-allows to manually control the ABS pump motor.
- ABS Version Test-displays the name of the brake system and the ABS controller version number, software ID, and sequence value.
- Actuator Tests–allows to manually control the actuators in order to test AYC valves, inlet valves, outlet valves, pump motors, and TRACS valves.
- Autobleed Test, Automated Bleed, or Service Bleed–removes air from the internal brake fluid chambers after servicing the brakes.

6.5 Steering Angle Sensor (SAS) Calibration

SAS Calibration menu let you perform calibration of the Steering Angle Sensor, which permanently stores the current steering wheel position as straight-ahead in the sensor EEPROM. On successful calibration of the sensor, its fault memory is automatically cleared.

6.6 Diesel Particulate Filter (DPF) Regeneration

DPF Regeneration menu let you perform the DPF cleaning to clear the blockage through continuous burning of the particulates captured in the DPF filter. When a DPF regeneration cycle is completed, the DPF light automatically goes off.

7 Data Management Operations

Data Management menu let you review stored screenshots and playback recorded live data.

Typical menu options include:

- Browse Picture
- Playback
- Stored Data Management

FOXWELL		12:00:03 🧿 🦞 🗙
	Data M	lanagement
	0	
Browse Picture	Playback	Stored Data Management

Figure 7-1 Sample Data Management Screen

7.1 Browse Picture

Browse Picture option leads to screens for review of stored screenshots. In case a failure of the GT80 applications occurs, please just take a screenshot and send it to our team to help with the troubleshooting of system faults.

7.1.1 How to Take a Screenshot

- To take a screenshot:
 - 1. Whenever you have an issue with the GT80 application, just press the

Camera button at the title bar of the screen to take capture the error.

2.Add a description of the error, and press the **OK** button to save.

		Dat	ta List		
Ti	st Graph	Graph Merge	Gauge	Study Mode	Comparison Mode
Index	Name		Reference	Value	Unit
141	injector 4 Pulse width			1	ms
142	legisclor 5 Pulse width	Fil	e Name	62	ms
143	Injector 6 Pulse width	20150326145825			m
144	Injector 7 Pulse width				1.40
145	Injector 8 Pulse width	ОК	Cancel		ITU
146	Injector 2 Pulse width			3	ms
147	Injector 3 Pulse width			1	ns
148	Viscous cooling fan pulse width	modulation control		0.00	
149	Universal heated exhaust can or	ygen heater pre-catalytic, bank 1.		0	ma

Figure 7-2 Sample Screenshot Screen

7.1.2 Review Screenshot

- To review the screenshot:
 - 1.Press the **Data Management** icon from the Home screen of GT80 diagnostic application.
 - 2. Press **Browse Picture** and all available pictures will be displayed as slideshow automatically.



Figure 7-3 Sample Browse Picture Screen

- 3.To stop the slideshow playing, just press the **Pause** button. Use **Next** or **Previous** button to review the pictures one by one.
- 4.To delete a picture, tap button **Delete** and answer **Yes** to delete. Or press **Delete All** to delete all the pictures.

7.2 Playback Data

The Playback option leads to screens for review of recorded live data. Playing back a recording is just like using the scan tool on a live vehicle. It let you review live data in text, graph and graph merging format. Playback speed and direction (forward or reverse) can also be controlled.

- ► To review recorded live data:
 - 1.Press the **Data Management** icon from the Home screen of GT80 diagnostic application.
 - 2. Press Playback and all available records display.



Figure 7-4 Sample Playback Screen

3. Tap a record once and press the **OK** button or tap the record twice to review. All recorded parameters display in text format by default.



Figure 7-5 Sample Data Stream Playback Screen

- 4.To view parameter graphs, press the **Graph** tab. And to merge the graphs, press the tab **Graph Merging**.
- 5. To move forward or reverse back of the playing, just drag the progress bar forward or reverse. To stop the playing of live data, press the **Pause** button.
- 6.To exit playback, press the **Back** button.
- 7.To delete a record, tap a record to select and then press the **Delete** button. Answer **Yes** to delete or answer **No** to quit.

7.3 Data Logging & Stored Data Management

The logging icon displays on the upper right side of the diagnostic screen whenever the scanner builds communication with the vehicle. Just click it to record the communication data between the scan tool and the vehicle under test to help with troubleshooting of diagnostic failures. The logs will be saved to the scanner and sent to our server via internet. To stop recording, please re-click the icon. To check the logs, please select **Stored Data Management** from **Data Management** and click the Upload button to send them to our server.

8 Client Management

The Client Management allows every workshop to record and manage their clients' vehicle information. When the plate and VIN of a vehicle is recorded, GT80 will recognize the car automatically so technicians do not have to make a lot of selections to identify the car. It makes it much easier for technicians to determine the car configurations and helps them focus on servicing the car.

9 Remote Control

Remote Control enables you to start TeamViewer for remote control when you need any supports from Foxwell support team.

- If you need Foxwell support team to remote control GT80, please do as follow:
 - 1.Click the Remote Control icon on the main menu of GT80 to start TeamViewer.

Connection Extras Help Beta Feed	hark 💦	Please sign in
+ Remote Control		
Freit Romoli (non-commercial use anty) - Foewell		
Allow Remote Control	Control Remote Computer	
Please tell your partner the following 80 and password if you would like to allow remote	Please enter your partner's ID in order to control the remote computer.	E-mail
140 691 173	Partner ID	Password
110 051 115	141	
9043	Remote control File transfer	Sign In
Enter a personal parsiend to access this, computer from anywhere.	Connect is partner	El Kerp me signed in
condition along advantage.	Consect in paramet	Forgot password
1		Sign Up
Ready to connect (secure connection)	E Computers & Contacts 🤉	

Figure 9-1 Sample Remote Control Screen

2.Send your ID and password to us to let our team to take control your tablet.

10 Setting

This section illustrates how to program the scanner to meet your specific needs.

When Setting application is selected, a menu with available service options displays. Menu options typically include:

- Language
- Display Mode
- Unit
- User Information
- Reset Setting



Figure 10-1 Sample Setting Screen

10.1 Language

Select Languge opens a screen that allows you to choose system languge. The scan tool is set to display English menus by default.

- To configure system language:
 - 1.Press the **Setting** icon from the Home screen of GT80 diagnostic application and select Language. Then all available language options display.
 - 2. Select your local language.

10.2 Change Display Mode

Selecting Display Mode opens a screen that allows you to toggle the display mode between full-screen view and display with Windows tool bar. The scan tool is set to display with full-screen view by default.

- To configure display mode:
 - 1.Press the **Setting** icon from the Home screen of GT80 diagnostic application.
 - 2. Press Display Mode and available modes display.
 - 3. Select a display mode.

10.3 Change Units

Selecting Unit opens a dialog box that allows you to choose between British customary or metric units of measure.

- To change the unit setup:
 - 1.Press the **Setting** icon from the Home screen of GT80 diagnostic application.
 - 2. Press Unit and available unit system display.
 - 3. Select a unit system.

10.4 User Information

Selecting User Information option opens a screen to input and manage your workshop information. Your workshop information will be displayed on your test reports that are presented to your customers.

- To input your workshop information:
 - 1. Press the **Setting** icon from the Home screen of GT80 diagnostic application.
 - 2. Select User Information option.
 - 3. Input your workshop name, phone and fax number and email address with the keypad.

10.5 Reset Setting

Selecting Reset Setting option lets you to reset your scan tool to factory defaults. This option will also clear the workshop information.

- To reset your scan tool to factory defaults:
 - 1. Press the **Setting** icon from the Home screen of GT80 diagnostic application.
 - 2. Select Reset Setting option.
 - 3. Press the **Reset** button. The scan tool reboots automatically and the reset is completed.

NOTE

It is suggested that the **Save** button not be pressed until you have finished all setups. The scanner will reboot automatically when the button is pressed.

11 About

Selecting **About** option opens a screen that show information about your scan tool, such as serial number and register password which may be required for product registration. To view the About page, please make sure the device is powered either by the AC/DC power supply or the vehicle through the Data Link Connector; otherwise you will not see the serial number and password of your scanner.

- To view information of your scan tool:
 - 1. Press the **About** icon from the Home screen of GT80 diagnostic application.
 - 2.A screen with detailed information of the scanner displays.

	About			
Hardware version:	1.01			
Software version:	1.02			
Serial number:	N80001G001001			
Date of production:	20141229			
Register password:	514988			
Copyright (c) 2014 F	oxwell Technology Co., Ltd. All righ	ts reserved.		

Figure 11-1 Sample Tool Information Screen

3. Press the Back button to exit.

12 Registration and Update

The scanner can be updated to keep you stay current with the latest development of diagnosis. This section illustrates how to register and update your scan tool. You can register both on Foxwell website or by the update client Foxscanner.

To update your scanner, please follow the three steps here below:

1.Obtain a FOXWELL ID.

2. Register the product with the product serial number and product password.

3. Update the product by the update application FoxScanner.

To be able to use FoxScanner, PC or laptop must meet the following minimum requirements:

- Operation System: Win98/NT, Win ME, Win2000, Win XP, VISTA and Windows 7 and Windows 8.
- CPU: Intel PIII or better
- RAM: 64MB or better
- Hard Disk Space: 30MB or better
- Display: 800*600 pixel, 16 byte true color display or better
- Internet Explorer 4.0 or newer

NOTE

Before registration and updating, please make sure your network works correctly.

12.1 Create a Foxwell ID

If you are new to FOXWELL, please register with FOXWELL and obtain a FOXWELL ID first. There are two methods to register an ID.

• Register with the built-in update client Foxscanner on GT80

• Register through our website. Please click the URL below:

http://www.foxwelltech.com/register/step_two.html

12.1.1 Register with Built-in Update Client FoxScanner

You are allowed to register and create a Foxwell ID with the built-in update client FoxScanner.

To register with FoxScanner:

1.Press the **Update** icon from the Home screen of GT80 diagnostic application, and the update client starts up automatically.

		1	×
2			
۹,			
Stay signed in	Forget password		
Sign in	Register		

Figure 12-1 Sample FoxScanner Main Screen

2. Click **Register** button, a Register window will pop up.

	Register	•
	• User Name	(Less than 30 characters)
	* Password	(6-16 characters)
-	Confirm Password	(The passwords must match.)
6	· First Name	
	Middle Name	
	Last Name	
	• Email	
	+ Telephone	(Numbers only)
	Address	
	· Country	
	State/Province	
	City	
	Zip Code	

Figure 12-2 Sample Register Screen

3.Create a unique user ID and password, complete the following registration form and click **Register** to confirm.

gister		
* User Name	Susan	(Less than 30 characters)
* Password		(6-16 characters)
* Confirm Password		(The passwords must match)
* First Name	Susan	
Middle Name		
* Last Name	Green	
* Email	sales2@foxwelltech.com	
* Telephone	8675526697229	(Numbers only)
Address		
* Country	CHINA	
State/Province	GUANGDONG	
City	SHENZHEN	
Zip Code	51800	_
	By creating an account, you agree to Foxwell's cond	itions of use and privacy notice.

Figure12-3 Sample Register Screen

4.A **Registration Done** message will appear if you registered successfully, and an email will be sent to your registered email address containing a link with which you can activate the Foxwell ID. Please log in your email and activate the account.

Register		×
Vser Name	Susan	(Less than 30 characters)
* Password		(6-16 characters)
* Confirm Password		(The passwords must match.)
* First Name	Susan	
Middle Name	FoxScanner.	
* Last Name	Green	
* Email	sales2@foxw Registration Done!	
* Telephone	8675526697:	(Numbers only)
Address		
* Country	CHINA 确定	
State/Province	GUANGDON	
City	SHENZHEN	
Zip Code	51800	
	By creating an account, you agree to Foxwell's conditi	ions of use and privacy notice.
	Register Res	et

Figure 12-4 Sample Registration Done Screen

5.Click **OK**. It skips to the log in page automatically. You can input your Foxwell ID and password to sign in.

FoxScanner V1.00	- x
FOXWELL	
	Susan
	A
	Stay signed in Forget pessword
	Sign in Register

Figure 12-5 Sample Log in Screen

12.1.2 Register through Website

To register through our website:

- 1. To create a Foxwell ID and register your scan tool
- a. Visit our site <u>www.foxwelltech.com</u> and then select Support>Register.

Product Support	News	Center Distributor	About Us	Contact Us	-	Q.
Régister	0.1	HOME > Support > FAQ	ITSXX and NT4XX	series scanners?		
FAQ	3	· Why can't I register my	scanner?			
Update	2.			S Trigger Tool NT 1001 7		
Support Tickel	- X - 2			may not be found at our websi	te anu louner?	
Warranty		How to find my Foxwell			Contraction of the contraction o	
Training	1.00	How to find my passwor				
		How to find the software	version number?			
		Why can't i find AU Fon	Holden or Brazila	m GM from Automaster Pro ser	ies-Scanners?	

Figure 12-6 Sample Register Screen

b. Click **Register** link at the top right of the website or at the lower side of home page.



Figure 12-7 Sample Register Screen

2.Create a unique user ID and password, complete the following registration form and then click Submit to confirm. When your ID has been created, you are allowed to view all programs associated with your tool, download updates, edit your profile, submit feedback and join our community to share your ideas and your stories about our products.

*Foxwell ID	Providence	Please create a unique user name as your Foxwell ID. Your phone number or email address
Troxwell ID	Foxwellsupport	is recommended.
*Password		The password must include 6-16 numbers (0-9) and letters. Use upper and lower case letters (A
*Confirm Password		Z, a-z) or symbols (?1@#) if you want to make o more secure.
*First Name	foxwell	
Middle Name		
*Last Name	puppert	
"Emoil	helen.ou@foxwelltech.com	This email is used to retrieve your password in case you forgot it. Please make sure the email
*Phone	88-755-26897229	you entered works correctly
Company		
Address 1		
Address 2		
City		
State/Province		
*Country	china	
Zip Code		
"Captcha	02V6 Click image to refresh	

Figure 12-8 Sample Registration Form Screen

IMPORTANT

Please always remember your FOXWELL ID and Password as it's important for you to manager your product and updates.

3.A **Submit OK** message will appear if you registered successfully and an email will be sent to your registered email address containing a link with which you can activate the Foxwell ID. Please log in your email and activate the account.



Figure 12-9 Sample Successful Registration Screen

IMPORTANT

Before activating and confirming your email address by clicking the activation link in your email, your account will still be invalid and you are not be allowed to sign in.

4. The registration page will be bypassed, skipping to the log in page. Just input your FOXWELL ID/email address and Password to sign in.

Product	Support	News Center	Distributor	About Us	Contact Us		Q,
Velcome to	Foxwell						
User Name	Fargót your use	er ID and/or passwor	17			foxwell? I it's easy and free	
		ed in (Uncheck if you'r		puter)		Register	

Figure 12-10 Sample Sign in Screen

5. When log in successfully, the **Member Center** will show as below. This platform enables you to review the registered products, register new products, modify personal information or reset the password.

My Products	Member Cent	er		Exit
Registered Products				
New Registration		088@163.com , Welco		
	IP of Last Login :	183,15,238,103	IP of This Login : 113.87.51.38	
My Message	Register Date : 2	0:51:12 07/02/2015	Date of Last Login : 20:51:12 07/02/2015	
My Messages	Account Overvi	ew		
Support Tickets				
My Orders	Open Orders : 1	Piece	Unread Messages : OPiece	
All Orders	Update News			
My Profile	N Product	Number	Available Updates	
Personal Information	o.			
Reset Password	1 NT500	1	Details	
	2 NT624	1	Details	
	3 NT401	1	Details	
	4 NT644	6	Details	
	5 GT80	4	Details	
	6 NT414	1	Details	
	7 VS500	1	Details	

Figure 12-11 Sample Member Center Screen

6.If you forget your register ID or password, just click **Sign in** at the top right of the website, then click **Forgot your user ID and/or password**? . You are required to either input the serial number and register password or your registered email address. Then our system will send a password reset link to your registered email address.

Password	
*Registered email or serial number *Register Password	 0

Figure 12-12 Sample Password Retrieval Screen

7.Please log in your email and click the link to go to the following **Reset Password** page. Input your new password and submit it. Now you are able to log in with your ID and the new password. If you want to change the password, please sign in with your user name and password, then select **My Profile/Reset Password**.

Product	Support	News Center	Distributor	About Us	Contact Us	_
Reset Passwo	ord					
	New Password	1				

Figure 12-13 Sample Password Retrieval Screen

NOTE

If the user name is different with the email you filled when registering, please input the registered email to find your password back, but not user name.

	Fill in your personal information						
*Foxwell ID	foxwell@gmail.com	Please create a unique user name as your Foxwell ID. Your phone number or email address is recommended.					
*Password		The password must include 6-16 numbers (0-9) and letters. Use upper and lower case letters (A-Z					
*Confirm Password		a-z) or symbols (?-!@#) if you want to make it more secure.					
*First Name	fox						
Middle Name							
"Last Name	support						
*Email	foxwell@foxwelltech.com	This email is used to retrieve your password in case you forgot it. Please make sure the email you					
*Phone	86-755-26697229	entered works correctly.					

Figure 12-14 Sample Different Email Address

12.2 Register Your Scanner

To register a scanner, you can either register on <u>www.foxwelltech.com</u> or by the built-in update client FoxScanner. Before registering your scanner, please make sure you have already created your Foxwell ID.

12.2.1 Register Through Website

1.Visit our website <u>www.foxwelltech.com</u> and click **Sign in** at the top right corner of home page. Input your FOXWELL ID/registered email and password to sign in.

=OXI	VEL	L			f	E	in 🖥	1	Worldwide	Register Sign
Product	Support	News Center	Distributor	About Us	Contact Us				-	à,
Welcome to	Foxwell									
Password		er ID and/or passwor ed in (Uncheck if you')		uputer)		Let's		to foxw editi's ca	ell? sy and free Registe	-

Figure 12-15 Sample Log in Screen

2. When log in successfully, the Member Center will show as below.

My Products	Me	mber Center				0.0
E Registered Products		lan , Welcome ! ast Login : 113.91.23	8.41	IP of This Login	: 1189152.164	
My Message	Register Date : 16:52:17 24/12/2014		Date of Last Log	Date of Last Login : 16:52:17 24/12/2014		
My Message	Account Overview					
III Support Tickets My Orders	Open Orders : 3Pleces		Unread Message	Unread Messages : OPlece		
🗄 All Orders	Regi	stration				
My Profile	No.	Product	Language	Register Date	Expire Date	
IE Personal Information	1	NT614	EN	17:27:09 24/12/2014	17:27:09 24/06/2016	
E Reset Password		Available Updates:	GM Ford OS-S	OFTWARE LandRover Jaguar Acura	Honda Hyundai OPEL Infiniti	
	2	NT614	EN	18:20:37 24/12/2014	18:20:37 24/06/2016	
		Available Updates:	GM Ford OS-S	OFTWARE LandRover Jaguar Acura	Honda Hyundai OPEL Infiniti	
	3	NT500 Available Updates:	EN	17:33:07 27/12/2014	17:33:07 27/06/2016	

Figure 12-16 Sample Member Center Screen

3. To register a product, please click **My Products>New Registration**. Select the right part number, input serial number and password and click the **Submit** button to complete product registration.

My Products	Product Registra	tion	Back Buck To Menu
E Registered Products			
E New Registration	Part number :	NT620/NT621/NT622/NT623/NT624 -	
My Message	Serial Number :	NF21201004389	
🗄 My Messagee	Password :	00aa99	
Support Tickets		1.200.0	
My Orders			
E All Orders		Submit	
My Profile			
E Personal Information			
E Reset Password			

Figure 12-17 Sample New Product Registration Screen

NOTE

To check the serial number and password of GT80, please select **About** on the GT80 main menu. Please make sure the device is powered either by the AC/DC power supply or the vehicle through the Data Link Connector; otherwise you will not see the serial number and password of your scanner.

12.2.2 Register With Built-in Update Client FoxScanner

- To register with FoxScanner:
 - 1. Press the **Update** icon from the Home screen of GT80 diagnostic application, and the update client starts up automatically. Log in with your Foxwell ID/ registered email and password.



Figure 12-18 Sample Log In Screen

2.Please select Register Products to register it. Select the right part number input serial number and password to complete product registration.

FoxSca	nner V1.00				- x
1		agster Products	My Prolite	Support Tickets	Pint
S/N R	egistration	S/N Managemer	a		
₩ Item ₩ 001 ₩ 002	Part Number NT614 NT620	Serial Number NF41401077063 NA41402078034	Password aa00bb ff22dd		
		ional number and regis	ter password		Submit

Figure 12-19 Sample New Product Registration Screen

12.3 Update the Scanner

NOTE

- Before updating, please make sure your network works correctly.
- Before updating, please make sure you have already created a Foxwell ID.

b To update your scanner:

1.Press the Update icon from the Home screen of GT80 diagnostic application, and the update client starts up automatically. Log in with your Foxwell ID/ registered email and password.



Figure 12-20 Sample Sign in FoxScanner Screen

2.Click My Updates-> Available Updates and all updates applicable to your scanner display.



Figure 12-21 Sample My Update Screen

3. Click the check box(s) in front of the software(s) you wish to update and then click the Update button to download.

Availa	ble Updates	loftware Manag	ement			
S	select SD Card K:\	1	-	Select Serial N	umber NF41406	002748 *
Item 001 002 003 004 005 006	Software ACURA FORD GM INFINITI OPEL OS-SOFTWARE	Version V5.10 V5.20 V5.20 V5.10 V6.00 V2.01	Language CNJEN CNJEN CNJEN CNJEN CNJEN CNJEN	Release Date 2014-08-06 2014-08-06 2014-08-06 2014-08-06 2014-08-06 2014-08-01	File Size	Current Status Updatable Updatable Updatable Updatable Updatable Updatable

Figure 12-22 Sample Update Check Screen

4. When Update button is clicked, it begins to download. And you can check the Current Status. If the Current Status shows Downloading, please do not close the update application.

		Productis Software Manag	My Pr jement	ofile	Support Tickets	Pant
	Select SD Card K			Select Serial N	umber N441309	000090
☐ Iter 00 ✓ 00.	ACURA	Version V5.20 V5.20	Language EN EN	Release Date 19/12/2014 06/08/2014	File Size 6.45 KB 22.01 MB	Current Status Update Donel Downloading 1.0%
ownlo	ading 2/2					

Figure 12-23 Sample Updating Screen

5. When all the items are updated, an "Update Done!" message displays and the Available Update items will be blank.



Figure 12-24 Sample Update Completed Screen

6.Please click Software Management to review all the updated software.



Figure 12-25 Sample Software Management Screen

NOTE

If "Update Failed" dialog comes up, it indicates that the software updates failed. Please check your network connection or SD card. If the problem still exists, please contact support@foxwelltech.com or your local dealer for assistance.

7.To uninstall a software or all software select them and click the Uninstall button. And the uninstalled items can be found in the Updates screen.

FoxSca	nner V1.0	00			- ×
My Up	A REAL PROPERTY OF A REAL PROPER	Register Products	My Profile	Support Tickets	Pint
Availa	ble Updates	Software Manager	nent		
001	Software Honda	Verson v5 20 The	softwares were just uninstalle		
Copyright (c) 20	14 Forwell Technolo	er Co. Int. All right recorrys	1		Uninstall erre formelitisch con

Figure 12-26 Sample Software Uninstallation Screen

8.Please click **My Profile** to view your personal information. To modify your personal information, just type in the message box and click **Submit**. To help us provide better service, please make sure that the telephone, email and country are correctly entered.

矛			
My Updates	Register Product	is My Profile	Support Tickets Pret
User Name	ygq7812088@163.	com	
· Full Name	Micheal		390201532@qq.com
* Email	390201532@qq.co	m	1
* Telephone	8675526697229		
* Address	m 411, Area C, Blo	ck E&F, Huafeng Technolog	y Park, Xinhu Road, Shenzhen 518100, China
* Country	China		
* State/Province	Guangdong		
City	Shenzhen		
Zip Code	51800		
		Submit	Reset

Figure 12-27 Sample My Profile Screen

9. Should you have any questions regarding the product, please click Support Tickets. Fill in all required information and click Submit to send us your issue.

0		
My Updates	Register Products My Publie Support Tickets	Pnnt
* Subject	NT644 09 Audi A5 TFSi	
- Scanner	NT644	1.
Software		
* Version	V5.2	
≠ VIN	WAUZZZ8T99A055468	
· Year	1999	
Engine Size		
* Problem Description	When analysing direct via the System Menu - Cent Elec the NT500 freezes at 'Communicating with vehicle please wait	
	Submit Reset	ini-

Figure 12-28 Sample Support Ticket Screen